

### KNIFE CARE

Simple regular maintenance is required for our Out The Front knives to deploy smoothly. This will help to prevent buildup of debris and keep the internals properly lubricated. Basic maintenance is the first step to take if your knife encounters any deployment issues.

# Cleaning Recommendations

Once a month, clean your knife by putting a few drops of a very light gun oil in the opening of the handle and blowing it out with compressed air. Doing so will keep the action of your knife working smoothly. To see these steps in action, visit support.microtechknives.com.

# KNIFE SHARPENING AND REPAIR

Disassembly and sharpening will not automatically void the warranty. These actions will void the warranty if the function of the knife is altered. We recommend customers take advantage of our professional maintenance and warranty services. To begin the process, please fill out the support ticket form at support.microtechknives.com.

#### **KNIFE STORAGE**

You may store your knife in an open or closed position. Please continue to lightly oil your knife every few months.

## **ONLINE RESOURCES**

Additional help, articles and videos available online at support.microtechknives.com.

FIND US ON







@microtechknivesofficial



## OPTIONAL PRODUCT REGISTRATION

We suggest you register your product online at microtechknives.com. This registration is not required for warranty coverage, but is helpful for our customer service efforts.

WARNING! This product may contain a chemical known to the state of California to cause cancer, birth defects or other reproductive harm

Microtech® and its designs are registered trademarks of Microtech® Knives Inc. All rights reserved. Any unauthorized reproduction of any materials herein is strictly prohibited by law.



# DUAL ACTION OPERATION

TO OPEN: All dual action OTF knives have a button that slides back and forth. Hold knife handle firmly with dominant hand. Make sure nothing is obstructing blade path (allow 12 inches). Using thumb (T) of same hand, push sliding button forward away from your wrist. If blade does not open all the way, see blade reset procedure.

BLADE RESET: If blade does not deploy fully, pinch top of blade at spine (A), keeping fingers away from sharp edge, and pull blade to fully extracted position until blade locks. After blade is fully deployed, use closing procedure.

Video available at support.microtechknives.com.



# WELCOME TO THE MICROTECH® FAMILY

Thank you for choosing Microtech. We believe that when you purchase a Microtech item, you have bought the best. Our talented associates work hard to ensure that every product surpasses your expectations. We stand behind our premium materials and quality craftsmanship. For more information on Microtech and our mission, please visit us at microtechknives.com.

#### LIMITED LIFETIME WARRANTY

Our warranty covers the function of the product (including internal parts) for the lifetime of the product, based on availability. Our warranty does not cover normal signs of wear and tear, cosmetic refurbishments, replacement parts, accidents, loss or theft.

For any warranty-related inquiries, visit our support portal at support.microtechknives.com.



TO CLOSE: Use your thumb in same manner as opening, this time with thumb (T) on top half of button pulling toward your wrist.

DISCLAIMER: Knives should be handled responsibly. Serious injury or death could occur if these instructions are not properly followed or understood.

Please do not attempt to open your knife if you are unable to do it properly, or while under the influence of drugs or alcohol.